

KÖSTER

Tehni ki podaci / Artikel broj

5.030

Važi od 11. Januar 2010

REPARATURNI MALTER

VODO-ODBOJNI, ZAVRŠNI MALTER ZA POPUNJVANJE I REPARACIJU

Opis

Reparaturni malter sa izuzetnim prijanjanjem ak i na površinu starih objekata. sa dodatkom SB Bonding Emulsion „Concetrate“ Moze se koristiti kao PCC (polimerom modifikovani cementni beton) malter.

Tehni ki podaci

Specifi na težina maltera	1.8kg/1
Otpornost na pritisak posle 7 dana	>18N/mm ²
Otpornost na pritisak posle 28 dana	>35N/mm ²
Otpornost do pucanja posle 7 dana	>4N/mm ²
Otpornost do pucanja posle 28 dana	> 6N/mm ²
Drugi sloj se nanosi za otprilike	24 sat

Polje primene

Reparaturni malter je pogodan za vodonepropusne reparacije. Uz to on se može koristiti za spravljanje vodonepropusnih gips smesa, sa kojima se izravnavaju hrapave površine ili spojevi, pre upotrebe tankih bitumenskih premaza, ak i pod vodom pod pritiskom. Pogodan je i kao malter za uzane prostore koji su predmet vode pod pritiskom, na spoju poda i zida, pre upotrebe bitumenskih premaza KÖSTER Bikuthan® 2C Supertight, KÖSTER Bikuthan® 1C Supertight, KÖSTER Deuxan® 2C Extratight, KÖSTER Deuxan Professional i mineralnih premaza (KÖSTER KD System, KÖSTER NB 1 Grey, itd.)

Podloga

Površina mora biti ista, zdrava, vrsta, o iš ena od ulja i masti, masnih boja i ostalih štetnih materija, koje mogu da spre e ili smanje prijanjanje. Prijanja na bilo koju mineralnu površinu. Pre postavljanja holkera na spoljnji podrumski zid naneti Koster NB 1 Grey (potrosnja oko 4kg/mm²). Ako se treba malterisati ve a površina koristiti mešavinu Reparaturnog maltera i vode u koju je dodato 25% SB Bonding Emulsion „Concetrate“ ..

Upotreba

30 kg reparaturnog maltera u 3-3.5 l vode + dodati 1 kg SB-Bonding Emulsion „Concetrate“. Sipati ¾ vodu pomešanu sa SB Bonding Emulsion „Concetrate“ u mešalicu odgovaraju e veli ine, dodavati prah i stalno mešati. Dodati ½ preostale vode i mešati dok malter ne postane homogen bez gromuljica. Vreme mešanja je oko 3min.

Aplikacija

Malter se mora ugraditi za maksimalno 3 sata. Koristiti obi ne

alate za malterisanje. Materijal se moze pripremiti i bez dodavanja SB Bonding Emulsion „Concetrate“, u tom slu aju dodati 1l vode

.Holkeri (kod voda pod pritiskom)

Na podlogu naneti Koster NB 1 Grey (potrošnja oko 4kg/mm²). Posle 24 sata uraditi holkere (duzine 4-6cm) koristeći ÖSTER Repair Mortar (30 kg KÖSTER Repair Mortar pomešanog sa 3 – 3.5 l vode + 1 l SB Bonding Emulsion „Concetrate“). Posle 24 sata holker može biti premazan Koster bitumenskim zaptiva em (na pr. KÖSTER Deuxan® 2C Extratight).

Potrošnja

Oko 1,8kg/l zapremine
18kg /m² /cm debljine
Oko 2.5 kg/ dužnom metru holkera.
iš enje alata
Posle upotrebe alat isprati vodom.

Pakovanje

30 kg vre a

Skladištenje

suvom i u originalnom pakovanju preko 6 meseci
Zaštita

Pri radu koristiti zaštitne nao are i rukavice.

Koriš eni citati tehni kih listova:

KÖSTER Bikuthan® 2C	Art.-No. 1.14
KÖSTER Bikuthan® 1C	Art.-No. 1.15
KÖSTER Deuxan® 2C	Art.-No. 1.16
KÖSTER Deuxan® Professiona	I Art.-No. 1.17
KÖSTER SB Bonding Emulsion	Art.-No. 2.11
KÖSTER KD System	Art.-No. 3.019
KÖSTER NB 1 Grey	Art.-No. 3.021

The accurate and thereby effective and successful application of our products is not subject to our control. The guarantee can therefore only be applied to the quality of our products within the scope of our terms and conditions, not, however, for their effective and successful application. These guidelines replace all previous ones.